

Roger Access Control System

MCT88M-IO Operating Manual

Product version: 1.0

Firmware version: 1.0.2.97 or newer

Document version: Rev. A



roger

1. DESIGN AND APPLICATION

The MCT88M-IO is an access terminal dedicated to RACS 5 system. The terminal is equipped with colour graphic display, sensor type keypad, 4 function keys and MIFARE Ultralight/Classic/DESFire/Plus/ reader. Users can identify at the terminal with PINs, MIFARE cards and mobile devices equipped with NFC (Near Field Communication) or BLE (Bluetooth Low Energy) technology. MCT88M-IO can be connected to RS485 bus of MC16 access controller directly or via MCX16-RS expander using Ethernet network (LAN). Alternatively the terminal can be connected to virtual controller through Ethernet network (LAN). When connected to MC16 controller it can be operated as access control terminal, Time&Attendance terminal and additionally it can be used to control the system especially in regard of building automation functionalities offered by RACS 5. When connected to virtual controller it can be operated as POS (Point of Sale) terminal or assets management terminal.

Characteristics

- RACS 5 system access terminal
- MIFARE Ultralight/Classic/DESFire/Plus cards reader
- NFC and BLE mobile device identification
- Colour graphic display
- Touch keypad
- 4 function keys
- 3 parametric (EOL) inputs
- 2 transistor outputs
- 1 relay output
- RS485 interface
- Ethernet (LAN) interface
- Dimensions: 155,5 x 85,0 21,5

Power supply

The terminal requires power supply voltage in range of 11-15VDC. It can be supplied from the MC16 access controller (e.g. TML output), from MCX2D/MCX4D expander or from dedicated power supply unit. The supply wire diameter must be selected in such way that the voltage drop between supply output and the device would be lower than 1V. The proper wire diameter is especially critical when device is located in long distance from the supply source. In such a case the use of dedicated power supply unit located close to the device should be considered. When separate power supply unit is used then its minus should be connected to controller's GND by means of signal wire with any diameter. It is recommended to use UTP cable for connection of device to controller. The table below shows maximal UTP cable lengths in relation to the number of wires used for power supply.

Table 1. Power supply cabling	
Number of UTP wire pairs for power supply	Maximal length of power supply cable
1	150m
2	300m
3	450m
4	600m




Fig. 1 MCT88M-IO supply from dedicated power supply unit




Fig. 2 MCT88M-IO supply from MC16 access controller

RS485 bus

The primary communication method with MC16 access controller is provided with RS485 bus which can encompass up to 16 devices of RACS 5 system, each with unique address in range of 100-115. The bus topology can be freely arranged as star, tree or any combination of them except for loop. The matching resistors (terminators) connected at the ends of transmitting lines are not required. In most cases communication works with any cable type (standard telephone cable, shielded or unshielded twisted pair etc.) but the recommended cable is unshielded twisted pair (U/UTP cat.5). Shielded cables should be limited to installations subject to strong electromagnetic interferences. The RS485 communication standard used in the RACS 5 system guarantees proper communication in a distance of up to 1200 meters as well as high resistance to interferences.

Ethernet interface

MCT88M-IO terminal can communicate with MC16 controller via LAN if MCX16-RS expander is connected as intermediary device (fig. 3). In such scenario, MC16 controller and MCX16-RS can be connected to the same network but they communicate solely via RS485 bus.

Alternatively, the Ethernet interface can be used for communication of the terminal with virtual controller which operates as Windows Service on a computer in LAN. Virtual controller enables the operation of MCT88M-IO as PoS terminal or assets management terminal. Virtual controller is a component of RogerSVC software package which is available at www.roger.pl.




Fig. 3 Connection of the terminal to MC16 controller via MCX16-RS expander

Keypad

The terminal is equipped with numeric touch keypad and backlight. The keypad can be used for user identification with PIN and for various keypad commands. By default, the key # is used for PIN confirming.

Function keys

The terminal is equipped with four touch function keys (fig. 4). Various functions can be assigned to these keys within high level configuration (VISO) e.g. Set T&A Mode, Register Guard Tour Event, Set Automation Node On, etc. Within low level configuration (RogerVDM) of the terminal it is possible to configure if the terminal distinguishes short and long key pressings. Consequently, each type of key press can be assigned with a different function.

Display

The terminal is equipped with a colour display (4 lines, 16 characters each). The display can be configured in regard of background and font colours within low level configuration (RogerVDM) and in regard of displayed information within high level configuration by means of *Display* command in VISO software navigation tree.

Moreover, default function key icons, splash screen, and screensaver can be replaced using a device memory card. Four new icons can be copied to the ICONS folder on the memory card (fig. 15) and they must be named as icon_001.bmp, icon_002.bmp, icon_003.bmp, and icon_004.bmp. The splash screen file in the same folder must be named as icon_000.bmp. Screensaver graphics must be named as scrnsvr.bmp and it must be copied to the main folder of the memory card instead of the ICONS folder. Icon files must be in bmp format, 60x60 pixels dimensions, and with 24-bit colour depth. Splash screen and screensaver pictures must be in bmp format, 320x240 pixels dimensions, and with 24-bit colour depth.




Fig. 4 LED indicators and function keys

LED indicators

The terminal is equipped with three LED indicators (fig. 4) which are used to signal integral functions and they can be additionally programmed with other available functions within high level configuration (VISO).

Table 2. LED indicators		
Indicator	Colour	Integral functions
LED STATUS	Red/green	Default indicator colour is red. If the terminal is assigned to Alarm Zone then the LED indicates zone arming (red) or disarming (green).
LED OPEN	Green	LED indicates access granting.
LED SYSTEM	Orange	LED indicates card reading and can signal other system functions including device malfunction.

Note: Synchronic pulsing of all three LEDs signifies lost communication with MC16 controller.


Buzzer

The terminal is equipped with buzzer which is used to signal integral functions and it can be additionally programmed with other available functions within high level configuration (VISO).

Inputs

The terminal offers 3 general purpose parametric inputs type NO/NC/EOL/DW and 1 input internally connected to tamper contact. Input types and electric parameters such as response time and parametric resistors are defined within low level configuration (RogerVDM). Input functions are assigned within high level configuration (VISO). Multiple functions can be assigned to the same input at the same time.


NO type



NO input can be in normal or in triggered state. In normal state CA contacts are opened. Input triggering is caused by CA contacts closing.

Fig. 5 NO input type


NC type



NC input can be in normal or in triggered state. In normal state CA contacts are closed. Input triggering is caused by CA contacts opening.

Fig. 6 NC input type


EOL/NO type



EOL/NO input can be in normal, triggered or tamper (sabotage) state. In normal state CA contacts are opened. Input triggering is caused by CA contacts closing. The change of RTamp resistor measured resistance in normal state indicates the tamper (sabotage) state.

Fig. 7 EOL/NO input type


EOL/NC type



EOL/NC input can be in normal, triggered or tamper (sabotage) state. In normal state CA contacts are closed. Input triggering is caused by CA contacts opening. The change of RTamp resistor measured resistance in normal state indicates the tamper (sabotage) state.

Fig. 8 EOL/NC input type


2EOL/NO type



2EOL/NO input can be in normal, triggered, tamper (sabotage) or malfunction state. In normal state CA contacts are opened, while CTamp contacts are closed. Input triggering is caused by CA contacts closing. CTamp contacts opening is recognized as the tamper (sabotage) state. Input shorting to the ground is recognized as the malfunction state.

Fig. 9 2EOL/NO input type


2EOL/NC type



2EOL/NC input can be in normal, triggered, tamper (sabotage) or malfunction state. In normal state CA and CTamp contacts are closed. Input triggering is caused by CA contacts opening. CTamp contacts opening is recognized as the tamper (sabotage) state. Input shorting to the ground is recognized as the malfunction state.

Fig. 10 2EOL/NC input type


3EOL/NO type



3EOL/NO input can be in normal, triggered, masking, triggered with masking, tamper (sabotage) or malfunction state. In normal state CA and CB contacts are opened while CTamp contacts are closed. Input triggering is caused by CA contacts closing. CB contacts closing is recognized as the masking state. Simultaneous closing of CA and CB contacts is recognized as the triggered with masking state. CTamp contacts opening is recognized as the tamper (sabotage) state. Input shorting to the ground is recognized as the malfunction state.

Fig.11 3EOL/NO input type

3EOL/NC type



3EOL/NC input can be in normal, triggered, masking, triggered with masking, tamper (sabotage) or malfunction state. In normal state CA, CB and CTamp contacts are closed. Input triggering is caused by CA contacts opening. CB contacts opening is recognized as the masking state. Simultaneous opening of CA and CB contacts is recognized as the triggered with masking state. CTamp contacts opening is recognized as the tamper (sabotage) state. Input shorting to the ground is recognized as the malfunction state.

Fig. 12 3EOL/NC input type

3EOL/DW/NO and 3EOL/DW/NC

These input types are operated in the same way as 3EOL/NO 3EOL/NC input types with the exception that masking state is interpreted as triggering of the second input. In VISO software DW input type is represented by two independent inputs. Each can be used for different purpose and assigned with different function.

Parametric resistors

The same values of parametric resistors are used for all inputs i.e. 1k Ω ; 1,2k Ω ; 1,5k Ω ; 1,8k Ω ; 2,2k Ω ; 2,7k Ω ; 3,3k Ω ; 3,9k Ω ; 4,7k Ω ; 5,6k Ω ; 6,8k Ω ; 8,2k Ω ; 10k Ω ; 12k Ω . Tamp resistor defines a value of resistor used to detect the tamper (sabotage) state. Alarm A resistor defines a value of resistor used to detect triggered state. Alarm B resistor defines a value of resistor used to detect an additional triggering state of 3EOL/DW input type or masking state of 3EOL input type. Alarm A resistor value must differ than value of Alarm B resistor at least by three positions in the list above. Total resistance of wire used to connect contacts to input should not exceed 100 Ω . Default values of parametric resistors:

- $T_{amp} = 1 \text{ k}\Omega$
- Alarm A = 2,2 k Ω
- Alarm B = 5,6 k Ω

Response time

Response time parameter defines minimal impulse time on the input which triggers the input. Each input can be configured individually in range of 50 to 5000 ms within low level configuration (RogerVDM).

Tamper detector

Built-in tamper (sabotage) detector enables detection of unauthorized opening of device's enclosure as well as detachment of the enclosure from wall. The detector is internally connected to the MCT88M-IO fourth input. It does not require low level configuration (RogerVDM) or any additional installation arrangements but it is essential to mount the terminal in such way that tamper lever (fig.16) would properly press the detector (fig. 15). The detector requires high level configuration which consists in assignment of the function [133] *Tamper Toggle* on the level of a *Main Board* of a controller in VISO software navigation tree.

Outputs

The terminal offers 2 transistor open collector type outputs (15V/150mA rated) and 1 relay output with NO/NC contacts (30V/1.5A DC/AC rated). Electric parameters such as polarity are configured within low level configuration (RogerVDM). Function are assigned to outputs within high level configuration (VISO). Multiple functions with different priorities can be assigned to the same output at the same time.

Identification

Following user identification methods are offered by the terminal:

- MIFARE Ultralight/Classic/Plus/DESFire proximity cards.

- PINs
- Mobile devices (NFC and BLE)

MIFARE cards

By default the terminal reads serial numbers (CSN) of MIFARE cards but it is possible to program cards with own numbers (PCN) in selected and encrypted sectors of card memory. The use of PCN prevents card cloning and consequently it significantly increases security in the system. More information on MIFARE card programming is given in AN024 application note which is available at www.roger.pl.

PINs

The terminal accepts variable length PINs (by default 4-8 digits).

Mobile devices (NFC and BLE)

The terminal MCT88M-IO enables user identification with mobile device (Android, iOS) using NFC or Bluetooth (BLE) communication. Prior to use of BLE/NFC identification on the terminal, within its low level configuration (see section 4) configure own *NFC/BLE authentication factor encryption key* and *NFC/BLE communication encryption key* while in case of Bluetooth additionally verify if the parameter *BLE activated* is enabled. Install Roger Mobile Key (RMK) app on mobile device and configure the same parameters as in the terminal. Create key (authentication factor) in RMK defining its type and number, then create the same authentication factor in VISO software (fig. 13) and assign it to the user with adequate Authorisation(s) at the terminal. When user wants to identify at the terminal using mobile device then key (authentication factor) can be selected from the screen or with gesture.




Fig. 13 Authentication factor type in VISO software

2. INSTALLATION




Fig. 14 Enclosure disassembly




Fig. 15 Internal side of the front panel

Table 3. Screw terminals	
Screw terminal	Description
OUT2	OUT2 output line
OUT1	OUT1 output line
IN3	IN3 input line
IN2	IN2 input line
IN1	IN1 input line
NO	REL relay output (NO)

NC	REL relay output (NC)
COM	REL relay common terminal
B	RS485 bus, line B
A	RS485 bus, line A
GND	Ground
+12V	12VDC power supply
1,2,3,4,5,6,7,8	Ethernet port




Fig. 16 Back panel

Installation guidelines

- The terminal should be mounted on a vertical structure (wall) away from sources of heat and moisture.
- The back panel should be mounted with included screws according to fig. 16 in such way as the tamper lever would firmly press the tamper switch.
- All electrical connections should be done with disconnected power supply.
- If the terminal and controller are not supplied from the same PSU then GND terminals of both devices must be connected with any wire.
- Clean front panel regularly by means of wet cloth and mild detergent. Do not clean by means of abrasive materials and strong cleaners like alcohols, solvents, etc. Damages to screen surface are beyond the scope of warranty.

3. OPERATION SCENARIOS

Access, T&A and building automation terminal

The MCT88M-IO terminal when connected to MC16 access controller can be at the same time used for access control, Time&Attendance and building automation functionalities. The example of connection diagram for such scenario is shown in fig. 17 where the terminal's power supply line and RS485 bus are connected directly to the controller and relay outputs of MCX8 expander are used to control building automation. Alternatively the communication with MC16 access controller can be provided via MCX16-RS expander (fig. 3). The terminal can also operate with MC16 controller using MCX2D/MCX4D expanders as in case of M16-PAC-x-KIT series.




Fig. 17 Typical connection diagram for the terminal and MC16 access controller

Vending terminal (PoS)

The MCT88M-IO terminal when connected to virtual controller via Ethernet (LAN) can be used as Point of Sale terminal. Virtual controller is a Windows Service installed on computer by means of RogerSVC software which is available at www.roger.pl.

Virtual controller with MCT88M-IO terminal can monitor and control products dispensing. Products are selected with terminal input lines (e.g. with connected button) and with function keys. The name of product is displayed by MCT88M-IO and after user identification (e.g. with proximity card) particular output line of the terminal is activated which on the other hand can be connected to vending machine dispenser or feeder. At the same time the controller deducts cost of the product from the user total limit which is defined by system administrator. The user can purchase certain amount of credits in advance or all costs can be settled when user leaves premises/hotel. The total amount of user's expenses are reported in VISO software and they can be made available to third party software through RACS 5 Integration Server.

Assets management terminal

The MCT88M-IO terminal when connected to virtual controller via Ethernet (LAN) can be used as terminal for management of assets under control of RACS 5 system. Virtual controller is a Windows Service installed on computer by means of RogerSVC software which is available at www.roger.pl. Assets management functionality requires licensed VISO EX software.

Virtual controller with MCT88M-IO terminal can monitor and control renting and returning of items by users. Rent or return function is selected with terminal input lines (e.g. with connected button) or with function keys. After user identification at the terminal (e.g. with proximity card) particular output line of the terminal can open lock to grant access to assets. It is possible to define users who can and cannot access assets. Assets must be assigned with identifiers so they could be recognized by the system. When asset is collected or returned by user then its identifier (proximity card, bar code, etc.) must be read/scanned. The virtual controller enables consolidated assets management and monitoring on the level of VISO software. More information on assets managements is given in AN026 Application note which is available at www.roger.pl.

4. CONFIGURATION

Low level configuration (RogerVDM)

The purpose of low level configuration is to prepare device for operation in RACS 5 system. In order to start the configuration, connect the terminal to RUD-1 interface (fig. 18) and start RogerVDM software.




Fig. 18 Connection to RUD-1 interface.

Programming procedure with RogerVDM software:

1. Place jumper on MEM contacts (fig. 15).
2. Connect the device to RUD-1 interface according to fig. 18 and connect RUD-1 to computer's USB port. The terminal will display CONFIG MODE text and orange LED SYSTEM will pulsate.
3. Start RogerVDM program, select *MCT* device, *v1.0* firmware version, *RS485* communication channel and serial port with RUD-1 interface.
4. Click *Connect*, the program will establish connection and will automatically display *Configuration* tab.
5. Select RS485 communication interface and specify unoccupied RS485 address in range of 100-115 or select Ethernet communication interface and specify IP address. Configure other low level configuration parameters as needed e.g. NC input type for IN1 input as for diagram in fig 17.
6. Click *Send to Device* to update the configuration of device.
7. Optionally make a backup by clicking *Send to File...* and saving settings to file on disk.
8. Remove jumper from MEM contacts and disconnect device from RUD-1 interface.

Note: If the USB port does not offer enough current then supply the terminal from external 12VDC PSU min. 200mA power output.

Note: Do not read any cards nor press reader keypad when reader is configured with RogerVDM.

Table 4. List of low level parameters	
Communication settings	
Communication interface	Parameter defines communication method of device with controller. Range: RS485, Ethernet. Default value: RS485.
IP address	Device IP address.
Subnet mask	Subnet mask.

Default gateway	Gateway IP address.
UDP port	UDP port
Ethernet encryption key	Parameter defines key for encryption of communication in Ethernet (LAN). Range: 1-16 ASCII characters.
RS485 address	Parameter defines device address on RS485 bus. Range: 100-115. Default value: 100.
RS485 communication timeout [s]	Parameter defines delay after which device will signal lost communication with controller. When set to 0 then signaling is disabled. Range: 0-64s. Default value: 20s.
RS485 encryption	Parameter enables encryption at RS485 bus. Range: [0]: No, [1]: Yes. Default value: [0]: No.
RS485 encryption key	Parameter defines key for encryption of communication at RS485 bus. Range: 4-16 ASCII characters.
NFC/BLE authentication factor encryption key	Parameter defines encryption key for NFC/BLE key (authentication factor). Range: 4-16 ASCII characters.
NFC/BLE communication encryption key	Parameter defines key for encryption of NFC/BLE communication. Range: 4-16 ASCII characters.
BLE authentication factor class	Parameter defines acceptable type of keys (authentication factors) created in Roger Mobile Key app for Bluetooth (BLE) communication. UCE means lower security and quicker identification while REK means higher security and slower identification. It is necessary to apply classes in RMK which are acceptable for terminal. Range: [1]: REK, [2]: UCE, [3]: UCE + REK. Default value: [3]: UCE + REK.
Optical signalisation	
LED SYSTEM pulsing when card near reader	Parameter enables LED SYSTEM (orange) pulsing when card is close to the device. Range: [0]: No, [1]: Yes. Default value: [0]: No.
Backlight level [%]	Parameter defines backlight level. When set to 0 then backlight is disabled. Range: 0-100. Default value: 100.
Backlight dimming when card/key used	Parameter enables temporary backlight dimming whenever card is read or key is pressed. Range: [0]: No, [1]: Yes. Default value: [0]: No.
LED SYSTEM flash after card read	Parameter enables short flash of LED SYSTEM (orange) when card is read. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
LED SYSTEM flash after key press	Parameter enables short flash of LED SYSTEM (orange) when key is pressed. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Acoustic signalisation	
Buzzer loudness level [%]	Parameter defines buzzer loudness level. When set to 0 then buzzer is disabled. Range: 0-100. Default value: 100.
Short sound after card read	Parameter enables short sound (beep) generating by buzzer when card is read. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Short sound after key press	Parameter enables short sound (beep) generating by buzzer when key is pressed. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Keypad settings	
Keypad activated	Parameter enables deactivation of keypad. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Time between keys in PIN [s]	Parameter defines max. time between two consecutive key pressings. Range: 0-64. Default value: 10.
Single key press	Parameter enables separate transmission of each pressed key to

	controller. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
PIN followed by [#] key	Parameter enables use of PINs with variable length. In such scenario PIN is concluded with [#] key. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Min. length of PIN	Parameter defines the minimal number of digits for PIN entered with keypad. If the number of entered digits is lower than this parameter then it cannot be sent to controller when concluded with [#] key. When set to 0 then PINs are disabled. Range: 4-8. Default value: 4.
Max. length of PIN	Parameter defines the maximal number of digits for PIN entered with keypad. If the number of entered digits reaches this parameter then PIN is automatically sent to controller and [#] key pressing is not necessary. When set to 0 then automatic PIN transmission is disabled. Range: 0-8. Default value: 8.
[*] key press allowed before PIN	The parameter enables use of [*] key before PIN is entered. The key can be used for additional functionalities. Range: [0]: No, [1]: Yes. Default value: [0]: No.
[*], [#], [F1], [F2], [F3], [F4] key press options	Parameter defines key press type for [*], [#], [F1], [F2], [F3], [F4] keys. Range: [1]: Short press only, [2]: Long press only, [3]: Short and long press. Default value: [1]: Short press only.
Advanced settings	
Card/PIN buffer timeout [s]	Parameter defines time for card/PIN storing in device buffer. When the time elapses the buffer is cleared even if card/PIN is not transmitted to controller. Range: 1-64. Default value: 10.
AF type	Parameter defines authentication factor type returned by terminal. Default value: [0010]: Number 40bits
Long card read time [s]	Parameter defines long card read time. When set to 0 then long read is disabled. Range: 0-64. Default value: 0
Long key press time [s]	Parameter defines long press time for [*], [#], [F1], [F2], [F3], [F4] keys. When set to 0 then long press is disabled. Range: 0-64. Default value: 2.
BLE session timeout [s]	Parameter defines maximal time for establishing connection between mobile device and terminal in Bluetooth technology. When timeout elapses the session is interrupted by terminal so mobile device could attempt to establish connection again. When set to 0 then timeout is disabled. Range: 0-10. Default value: 3.
BLE broadcasting power [dBm]	Parameter defines power of broadcasting radio signal for Bluetooth communication. Range: [1]: -18, [2]: -12, [3]: -6, [4]: -3, [5]: -2, [6]: -1, [7]: 0. Default value: [1]: -18.
BLE transmission power [dBm]	Parameter defines power of transmission radio signal for Bluetooth communication. Range: [0]: Auto; [1]: -18, [2]: -12, [3]: -6, [4]: -3, [5]: -2, [6]: -1, [7]: 0. Default value: [0]: Auto.
Input types	
IN1, IN2, IN3	Parameter defines input type. Range: [1]: NO, [2]: NC, [3]: EOL/NO, [4]: EOL/NC, [5]: 2EOL/NO, [6]: 2EOL/NC, [7]: 3EOL/NO, [8]: 3EOL/NC, [9]: 3EOL/DW/NO, [10]: 3EOL/DW/NC. Default value: [1]: NO.
Input response times	
IN1, IN2, IN3 [ms]	Parameter defines minimal duration of pulse which is required to trigger the input. Range: 50-5000. Default value: 50.
Parametric (EOL) input resistances	

Tamper, Alarm A, Alarm B [Ohm]	Parameter defines resistor for parametric (EOL) inputs.
Output polarity	
OUT1, OUT2, REL1	Parameter defines polarity of output. Normal polarity means that the output by default is switched off while Reversed polarity means that the output by default is switched on. Range: [0]: Normal polarity, [1]: Reversed polarity. Default value: [0]: Normal polarity.
Display	
Default background colour	Parameter defines default colour of font background.
Default font colour	Parameter defines default colour of fonts.
Default font background colour	Parameter defines default colour of font background.
File name with additional characters	File name with additional characters.
Screensaver	Parameter enables screensaver displaying. Range: [0]: No, [1]: Yes. Default value: [0]: Yes.
Screensaver display delay [s]	Parameter defines inactivity time before screensaver displaying. Range: 0-3600. Default value: 60.
Comments	
DEV, KBD1, CDI1, IN1, IN2, IN3, IN4 (Tamper), OUT1, OUT2, REL1,	Parameter defines any text or comment which corresponds to the object. It is later displayed in VISO program.
Serial card number (CSN) settings	
Serial number length (CSNL) [B]	Parameter defines the number of bytes from serial card number (CSN) which will be used to generate returned card number (RCN). RCN is the actual card number read by reader and it is created as sum of serial card number (CSN) and programmable card number (PCN).
Programmable card number (PCN) settings for Mifare Ultralight	
Sector type	Parameter defines sector type with programmable number (PCN). If the option [0]:None is selected then card returned number (RCN) will include only CSN and PCN will be discarded. Range: [0]: None, [1]: SSN. Default value: [0]: None.
SSN first page number	Parameter defines location of SSN in card memory. Range: 4-12. Default value: 4.
Programmable card number (PCN) settings for Mifare Classic	
Sector type	Parameter defines sector type with programmable number (PCN). If the option [0]:None is selected then card returned number (RCN) will include only CSN and PCN will be discarded. Range: [0]: None, [1]: SSN, [2]: MAD. Default value: [0]: None.
Format	Parameter defines format of PCN. Range: [0]: BIN, [1]: ASCII HEX. Default value: [0]: BIN.
First byte position (FBP)	Parameter defines the position of the first byte for PCN in data block on card. Range: 0-15. Default value: 0.
Last byte position (LBP)	Parameter defines the position of the last byte for PCN in data block on card. Range: 0-15. Default value: 7.
Sector ID	Parameter defines sector number where PCN is stored. Range: 0-39. Default value: 1.
Application ID (AID)	Parameter defines application ID number (AID) which indicates sector where PCN number is stored. Range: 0-9999. Default value: 5156.

Block ID	Parameter defines block number where PCN is stored. Range: 0-2 to for sectors 0-31 and 0-14 for sectors 32-39. Default value: 0.
Key type	Parameter defines key type used to access sector with PCN. Range: [0]: A, [1]: B, [2]: Roger. Default value: [0]: A.
Key	Parameter defines 6 bytes (12 HEX digits) key for accessing sector where PCN is stored.
Programmable card number (PCN) settings for Mifare Plus	
Sector type	Parameter defines sector type with programmable number (PCN). If the option [0]:None is selected then card returned number (RCN) will include only CSN and PCN will be discarded. Range: [0]: None, [1]: SSN, [2]: MAD. Default value: [0]: None.
Format	Parameter defines format of PCN. Range: [0]: BIN, [1]: ASCII HEX. Default value: [0]: BIN.
First byte position (FBP)	Parameter defines the position of the first byte for PCN in data block on card. Range: 0-15. Default value: 0.
Last byte position (LBP)	Parameter defines the position of the last byte for PCN in data block on card. Range: 0-15. Default value: 7.
Sector ID	Parameter defines sector number where PCN is stored. Range: 0-39. Default value: 1.
Application ID (AID)	Parameter defines application ID number (AID) which indicates sector where PCN number is stored. Range: 0-9999. Default value: 5156.
Block ID	Parameter defines block number where PCN is stored. Range: 0-2 to for sectors 0-31 and 0-14 for sectors 32-39. Default value: 0.
Key type	Parameter defines key type used to access sector with PCN. Range: [0]: A, [1]: B. Default value: [0]: A.
Programmable card number (PCN) settings for Mifare Desfire	
Sector type	Parameter defines sector type with programmable number (PCN). If the option [0]:None is selected then card returned number (RCN) will include only CSN and PCN will be discarded. Range: [0]: None, [1]: Desfire file. Default value: [0]: None.
Format	Parameter defines format of PCN. Range: [0]: BIN, [1]: ASCII HEX. Default value: [0]: BIN.
First byte position (FBP)	Parameter defines the position of the first byte for PCN in data block on card. Range: 0-15. Default value: 0.
Last byte position (LBP)	Parameter defines the position of the last byte for PCN in data block on card. Range: 0-15. Default value: 7.
Application ID (AID)	Parameter defines application ID number (AID) which indicates sector where PCN number is stored. Range: 0-9999. Default value: F51560.
File ID (FID)	Parameter defines file identifier in AID. Range: 0-32 for Desfire EV1 and 0-16 for Desfire EV0. Default value: 0.
Communication protection level	Parameter defines encryption method for communication between card and reader. Range: [0]: Plain, [1]: Data authentication by MAC, [2]: Full encryption. Default value: [0]: Plain.
Key number	Parameter defines application key number used for file read. Range: 0-13. Default value: 0.
Key type	Parameter defines encryption key type for Desfire file. Range: [0]: TDES Native, [1]: TDES Standard, [2]: 3-KTDES, [3]: AES128. Default value: [0]: TDES Native.

Key	Parameter defines access key for Desfire file with PCN. 3-KTDES key is 24 bytes (48 HEX digits), TDES and AES keys are 16 bytes (32 HEX digits).
-----	--

Manual addressing

Manual addressing procedure enables configuration of new RS485 address with all other settings unchanged.

Manual addressing procedure:

1. Remove all connections from A and B lines.
2. Place jumper on MEM contacts (fig. 15).
3. Restart the device (switch power supply off and on). The terminal will display CONFIG MODE text and orange LED SYSTEM will pulsate.
4. Enter 3 digits of RS485 address in range of 100-115 with keypad.
5. Wait till device starts to emit continuous sound.
6. Remove jumper from MEM contacts and restart the device.

Memory reset procedure

Memory reset procedure resets all settings to factory default ones including ID=100 address.

Memory reset procedure:

1. Remove all connections from A and B lines.
2. Place jumper on MEM contacts (fig. 15).
3. Restart the device (switch power supply off and on). The terminal will display CONFIG MODE text and orange LED SYSTEM will pulsate.
4. Read any MIFARE card 11 times.
5. Wait till device confirms reset with continuous sound.
6. Remove jumper from MEM contacts and restart the device.

High level configuration (VISO)

The purpose of high level configuration is to define logical functioning of the terminal which communicates with the MC16 access controller and it depends on applied scenario of operation. The example of access control system configuration is given in AN006 application notes which is available at www.roger.pl.

5. FIRMWARE UPDATE

New firmware can be uploaded to the terminal by means of included memory card. The latest firmware file is available at www.roger.pl.

Firmware update procedure:

1. Disconnect power supply.
2. Press and remove memory card from socket (fig. 15).
3. Using memory card reader, copy main firmware (*.frg) to the card and rename it as FW.BUF. Copy additional firmware (*.cyacd) for keypad and BLE and rename it as KBDFW.CYA.
4. Insert the card into socket.
5. Connect power supply and wait till device completes starting procedure. The progress of additional firmware uploading is shown on the display.
6. Disconnect power supply when additional firmware KBD is 100% uploaded.
7. Connect power supply and wait till device completes starting procedure.
8. Start RogerVDM and perform low level configuration.

Note: During the firmware update process, it is necessary to ensure continuous and stable power supply for the device. If interrupted the device may require repair by Roger.

6. SPECIFICATION

Table 5. Specification	
Supply voltage	Nominal 12VDC, min./max. range 10-15VDC
Current consumption (average)	~110 mA
Inputs	Three parametric inputs internally connected to the power supply plus (+12V) through a 5.6k Ω resistor, approx. 3.5V triggering level when configured as NO or NC.
Relay output	Relay output with single NO/NC contacts, rated 30V/1.5A
Transistor outputs	Two (IO1,IO2) open collector outputs, 15VDC/1A rated
Tamper protection	Enclosure opening reported to access controller
Identification methods	ISO/IEC14443A MIFARE Ultralight, Classic, Desfire EV1 and Plus proximity cards Mobile device (Android, iOS) compatible with NFC Mobile device (Android, iOS) compatible with Bluetooth Low Energy v4.1
Reading range	Up to 7 cm for MIFARE and NFC Up to 10 m for BLE – depends on ambient conditions and particular mobile device. Terminal's radio power can be increased within low level configuration.
Distances	Up to 1200 m between controller and terminal (RS485)
IP Code	IP41
Environmental class (acc. to EN 50133-1)	Class I, indoor general conditions, temperature: +5°C to +40°C, relative humidity: 10 to 95% (no condensation)
Dimensions H x W x D	85 x 155,5 x 21,5 mm
Weight	190g
Certificates	CE

7. ORDERING INFORMATION

Table 6. Ordering information	
MCT88M-IO	MIFARE DESFire/Plus access terminal; keypad; 4 function keys; colour display; on-board I/Os; RS485; Ethernet.
MCX8-BRD	I/O expander; 8 supervised inputs; 8 relay outputs 1.5 A/30 V; 13.8 VDC supply input.
RUD-1	Portable USB-RS485 communication interface dedicated to ROGER access control devices.

8. PRODUCT HISTORY

Table 7. Product history		
Version	Date	Description
MCT88M-IO v1.0	04/2018	The first commercial version of product



This symbol placed on a product or packaging indicates that the product should not be disposed of with other wastes as this may have a negative impact on the environment and health. The user is obliged to deliver equipment to the designated collection points of electric and electronic waste. For detailed information on recycling, contact your local authorities, waste disposal company or point of purchase. Separate collection and recycling of this type of waste contributes to the protection of the natural resources and is safe to health and the environment. Weight of the equipment is specified in the document.

Contact:
Roger sp. z o.o. sp.k.
82-400 Sztum
Gościszewo 59
Tel.: +48 55 272 0132
Fax: +48 55 272 0133
Tech. support: +48 55 267 0126
E-mail: biuro@roger.pl
Web: www.roger.pl